

For a 300 cm^3 sample bottle, the following equation relates PPM by weight N_2 in liquid argon to sample bottle pressure

PPM_w = Parts per million nitrogen in liquid argon by weight.

$psig$ = Sample bottle pressure, cryostat assumed to be at 2 psig.

$depth$ = indicated liquid depth, level probe must be submerged to use this equation.

$$PPM_w = \frac{45.94 \times psig}{11.42 \times depth + 104.2}$$

$$\frac{PPM_w \times (11.42 \times depth + 104.2)}{45.94} = psig$$