



**LAPD CRYOGENIC SYSTEM**

**CRYOGENIC CONTROL SYSTEM,  
INSTRUMENTATION, and FIELD EQUIPMENT**

Location: FermiLab\PC4\Fixed Target Enclosure

Electrical Engineering:

Dan Markley [dmarkley@fnal.gov](mailto:dmarkley@fnal.gov) x2670

Mechanical Engineering:

Terry Tope [tope@fnal.gov](mailto:tope@fnal.gov) x2666

**ENGINEERING NOTE**  
**REVISION A - NOV 8,2012**

**Author: Dan Markley**  
**Fermi Accelerator Lab**  
**PPD/MD/PROCESS CONTROLS ENGINEERING**  
**MAY 9,2011**

## CONTENTS

- I. Introduction
- II. Cryogenic Control System
  - a. Description
  - b. Electric Power and Circuit Protection
- III. Field Devices and Components
  - a. Heater HTR612A
    - i. Description
    - ii. Electric Power and Circuit Protection
  - b. Heater HTR634A
    - i. Description
    - ii. Electric Power and Circuit Protection
  - c. Heater HTR1\_TANK\_A(HTR385A-HTR396A)
    - i. Description
    - ii. Electric Power and Circuit Protection
  - d. Heater HTR2\_TANK\_A(HTR397A-HTR408A)
    - i. Description
    - ii. Electric Power and Circuit Protection
  - e. VFD(Variable Frequency Drive) LAR Pump
    - i. Description
    - ii. Electric Power and Circuit Protection
  - f. ODH Control system
    - i. Description
    - ii. Electric Power and Circuit Protection
  - g. Electric Vaporizer
    - i. Description
    - ii. Electric Power and Circuit Protection
  - h. U.P.S
    - i. Description
    - ii. Electric Power and Circuit Protection
- IV. References
  - a. Drawings
  - b. Documents

## Revision History:

### Rev A

PC4 ODH classification changed from Class 1 to Class 0  
ODH system adds two MSA O2 sensors to accommodate LBNE 35 ton  
ODH wiring Diagram 3942.510.EE-489928 replaces 3942.510.EE-486487  
3942.510.ME-444897 LAPD P&ID rev K updated to Rev M  
3942.520.EE-466801 PLC wiring diagram updated to Rev D

## **I. Introduction**

This document fulfills electrical documentation requirements set forth by the Electrical Design Standards for Electronics to be used in Experiment Apparatus at Fermilab document and EED/Infrastructure Doc. No:H011228A document published by the PPD/Electrical department.

The LAPD cryogenic test system is currently in the PC4 Underground Hall at FermiLab. The PC4 hall is classified as ODH class 0 area and has several large cryogenic and gas components. Cryogens include liquid Argon and Liquid Nitrogen.

This cryogenic system has approximately 100 electronic input sensing devices and 25 output devices. Input devices include RTD's, pressure transmitters, level transmitters, and thermocouples. Output devices include solenoid valves, variable speed motor controllers, and heaters.

There is no floor plan provided in this document due to the fact that all equipment is located in one area of PC4 and is clearly labeled.

All electronic and electrical control system equipment is air cooled and does not require any forced air cooling or water cooling. Cabinet air vents are provided for certain devices where appropriate.

The control system equipment components are all commercially available products which are UL listed. The cryogenic control system has been designed and built following all the required rules and standards such as the NEC. All premises wiring was installed by Fermi Electrical contractors and licensed electricians.

## **II. Cryogenic Control System**

### **a. Description**

The LAPD cryogenic system will be controlled by a Siemens S7-400 PLC with S7-300 associated I/O modules networked on a Profibus network. This PLC system will be programmed using the Siemens S7 engineering programming software.

Human machine Interface controls will be provided through GEFANUC's iFIX software. iFIX connects to the S7-400 through Private Ethernet using an OPC driver purchased from Kepware. iFIX will handle all operator security, computer alarming, and remote operator controls via the PPD-iFIX server. iFIX will also provide historical data through the PPD-iFIX historian. This historical data will be viewable in iFIX picture displays or on the web through the iFIX proficy portal server //on D0-HIST2/proficyportal machine.

### **b. Electric Power and Circuit Protection**

Sheet 1 of drawing "3942.520.EE-466801 LAPD S7 PLC wiring diagram rev D" shows the PLC cabinet equipment layout. It also shows the AC and DC power distribution and circuit protections. All conductors are either copper or tinned copper grade.

#### **AC Circuit Conductor:**

Min of 12 AWG downstream of 20A or less circuit protection

Min of 14 AWG downstream of 15A or less circuit protection

Min of 16 AWG downstream of 10A or less circuit protection

#### **DC circuit Conductor AWG:**

Min of 14 AWG downstream of 15A or less circuit protection

Min of 16 AWG downstream of 10A or less circuit protection

Min of 22 AWG downstream of 5A or less circuit protection





### **III. Field Devices and Components**

#### **a. Heater HTR612A**

##### **i. Description**

Heater 612A is a commercial 1200 watt Omega in line gas heater. This heater has an analog power control circuit for variable power control. The heater has an internal "k" thermocouple which is connected to a limit control device with an independent power disconnect relay. This limit control device has a mechanical dial which sets the high temperature trip limit temperature. This limit control device will protect the heater element from destructive high heater temperatures caused by equipment malfunctions and operator errors.

##### **ii. Electric Power and Circuit Protection**

Heater 612A is powered by 208VAC 1 phase power. The power is fed from a premises powered outlet. The heater control box is connected to this outlet using a standard molded ac cord. The heater control box has internal fuses on the heater power circuit and the control circuit. The downstream conductors are sized and rated to meet the minimum current capacity of these fuses. See illustration 2.

#### **b. Heater HTR634A**

##### **i. Description**

Heater HTR634A is a commercial 1200 watt Omega in line gas heater. This heater has an analog power control circuit for variable power control. The heater has an internal "k" thermocouple which is connected to a limit control device with an independent power disconnect relay. This limit control device has a mechanical dial which sets the high temperature trip limit temperature. This limit control device will protect the heater element from destructive high heater temperatures caused by equipment malfunctions and operator errors.

##### **ii. Electric Power and Circuit Protection**

Heater HTR634A is powered by 208VAC 1 phase power. The power is fed from a premises powered outlet. The heater control box is connected to this outlet using a standard molded ac cord. The heater control box has internal fuses on the heater power circuit and the control circuit. The downstream conductors are sized and rated to meet the minimum current capacity of these fuses. See illustration 2.




Illustration 2

**c. Heater HTR1\_TANK\_A(HTR385A-HTR396A)**

**i. Description**

Heater HTR1\_TANK\_A is a network of WatLow Polyimide flexible heaters attached to the LAr vessel. The network consist of 6 parallel groups of two series heaters. Each heater is rated for 100 watts, but there are two in series for an expected power of 50 watts each. This heater has an analog power control circuit for variable power control. Each group of two heaters has an RTD sensor between the two heaters which is readout by the S7 PLC system. All six RTD sensors in this heater network will be monitored and interlocked by the PLC. Special attention will be paid to these RTD for high temperature interlocks. This heater control system has a separate power relay from the analog control circuit which is controlled by the S7 PLC and functions as a power cutout to the heaters on an interlock.

**ii. Electric Power and Circuit Protection**

Heater HTR1\_TANK\_A is powered by 208VAC 1 phase power. The power is fed from a premises powered outlet. The heater control box is connected to this outlet using a standard molded ac cord. The heater control box has internal fuses on the heater power circuit and the control circuit. The downstream conductors are sized and rated to meet the minimum current capacity of these fuses. See illustration 3.


**d. Heater HTR2\_TANK\_A(HTR397A-HTR408A)**

**i. Description**

Heater HTR2\_TANK\_A is a network of WatLow Polyimide flexible heaters attached to the LAr vessel. The network consist of 6 parallel groups of two series heaters. Each heater is rated for 100 watts, but there are two in series for an expected power of 50 watts each. This heater has an analog power control circuit for variable power control. Each group of two heaters has an RTD sensor between the two heaters which is readout by the S7 PLC system. All six RTD sensors in this heater network will be monitored and interlocked by the PLC. Special attention will be paid to these RTD for high temperature interlocks. This heater control system has a separate power relay from the analog control circuit which is controlled by the S7 PLC and functions as a power cutout to the heaters on an interlock.

**ii. Electric Power and Circuit Protection**


Heater HTR2\_TANK\_A is powered by 208VAC 1 phase power. The power is fed from a premises powered outlet. The heater control box is connected to this outlet using a standard molded ac cord. The heater control box has internal fuses on the heater power circuit and the control circuit. The downstream conductors are sized and rated to meet the minimum current capacity of these fuses. See illustration 3.



### i. Description

## ii. Electric Power and Circuit Protection

The VFD is fed from premises power with a fused disconnect within sight of the VFD and motor. The VFD will be programmed with the motor data. The VFD has numerous internal motor protection settings which will interlock the motor power upon a fault.



### Illustration 4

## **f. ODH Control System**

### **i. Description**

The ODH system has been upgraded to handle up to four MSA O2 heads. Two O2 heads are currently in service for the LAPD vessel, with another two O2 sensors reserved for the LBNE 35 ton tank area.

The ODH system currently deploys two MSA O2 heads in the PC4 hall, these two sensors are near the LAr vessel. These sensors are about a foot off the floor. There are two sets of ODH warning horns and strobe lamps, one set is located at the PC4 ground level entry and the other set is located in the PC4 hall near the LAr vessel. There are two ventilation fans that pull air out of the PC4 hall and vent it outside. These fans are controlled by the S7 PLC and can also be run locally using a switch mounted near the fan unit. The ODH system is hardwired to both fans such that during an ODH alarm both fans run.

The O2 Sensors are MSA model A-UltimaX-PL-A-14-03D2-0000-100 and have a span of 0-25%. Each O2 sensor is wired to an MSA electronic controller which provides an analog output signal wired to the S7 PLC. This MSA electronic unit also provides relays which have three O2 level alarms thresholds, 18.5%, 18%, and 17.5%. The relay output that is set at 18.5% is wired directly to the ODH warning horns and strobe lamps located in PC4 and FIRUS. The MSA electronic unit also provides a trouble relay output which is also wired to the PLC and FIRUS. The trouble output is a wired in a failsafe manner, such that loss of power or blown fuse to the ODH controls will generate a trouble alarm.

### **ii. Electric Power and Circuit Protection**

The MSA equipment is wired directly to its own self contained control circuitry in its own enclosure which can be seen in illustration 5. This self contained enclosure has its own power supply which is independent of the PLC control system, allowing the ODH system to function independently of the PLC control system. The power for this ODH system comes from the UPS.




Illustration 5

## **h. Electric Vaporizer**

### **i. Description**

The electric vaporizer is a commercial heater unit which heats two phase gas up to about room temperature. It operates on 480VAC 3 phase power. The temperature controls are self contained and provided by the manufacturer.

### **ii. Electric Power and Circuit Protection**

The electric vaporizer is fed from premises power with a fused disconnect within sight of the unit.

## **i. U.P.S**

### **i. Description**

The control system U.P.S. is commercial 1.5 kw unit manufactured by Best power. The U.P.S. input power is fed from a premises powered outlet using the U.P.S. input line cord.

### **ii. Electric Power and Circuit Protection**

The U.P.S. has standard outlets located on the rear of the cabinet. An APC surge protector is located on the U.P.S. and its input power cord is plugged into the U.P.S output outlets. All relevant control system loads are plugged into the APC surge protector output outlets.

## **IV. References**

### **a. Drawings**


3942.510.ME-444897 LAPD P&ID rev M  
3942.520.EE-466801 LAPD S7 PLC wiring diagram rev D  
3942.520.EE-446145 LAPD Regeneration Gas heater wiring rev A  
3942.520.EE-486142 LAPD Tank Gas heater wiring rev A  
3942.520.EC-486497 LAPD LAr pump wiring rev A  
3942.510.EE-489928 LBNE 35 ton ODH control system wiring rev A

### **b. Documents**

Electrical Design Standards for Electronics to be used in Experiment Apparatus at Fermilab

EED/Infrastructure Doc. No:H011228A







REV	DESCRIPTION	DRAWN	DATE
A	ADDED TAG NUMBERS TO VALVE TYPES	V. MAJDANSKI	25FEB08
B	MOVE CONDENSOR OUTSIDE TANK	R. SCHMITT	26FEB08
C	MISC. REVISIONS MADE.	J.CATALANELLO	07-DEC-2008
D	MISC. REVISIONS MADE.	R. SCHMITT	10-DEC-2008
E	MISC. REVISIONS MADE.	J.CATALANELLO	23-DEC-2008
F	MISC. REVISIONS MADE.	R. SCHMITT	06-JAN-2009
G	MISC. REVISIONS MADE.	J.CATALANELLO	17-NOV-2009
H	MISC. REVISIONS MADE.	T.TOPE	14-DEC-2009
I	MISC. REVISIONS MADE.	J.CATALANELLO	17-NOV-2009
J	MISC. REVISIONS MADE.	T.TOPE	15-JAN-2010

- NOTES
1. VALVE TO REMAIN LOCKED CLOSED DURING NORMAL LAPD CRYOGENIC OPERATIONS. VALVE MAY ONLY BE UNLOCKED AND OPENED BY A PPD/MD/F&T ENGINEER FOLLOWING A RELEVANT PROCEDURE.
  2. VALVE TO REMAIN LOCKED CLOSED DURING LAPD CRYOGENIC OPERATIONS.



UNLESS OTHERWISE SPECIFIED			
ORIGINATOR	R. SCHMITT	26-JUN-2007	
DRAWN	J. CATALANELLO	07-DEC-2007	
CHECKED	R. SCHMITT	12-DEC-2007	
APPROVED	R. SCHMITT	12-DEC-2007	
USED ON			
MATERIAL			
FERMI NATIONAL ACCELERATOR LABORATORY UNITED STATES DEPARTMENT OF ENERGY			
FLARE UTILITIES GAS PIPING & INSTRUMENT DIAGRAM LIQUID ARGON PURITY DEMONSTRATION			
SCALE	DRAWING NUMBER	SHEET	REV
NONE	3942.510-ME-444897	1 OF 4	M
Created: 08:12:02 on 10-10-12 (D-M-Y) By: ccaton State: 1-INITIAL			




UNLESS OTHERWISE SPECIFIED			
ORIGINATOR	R. SCHMITT	26-JUN-2007	
DRAWN	J. CATALANIELLO	07-DEC-2007	
CHECKED	R. SCHMITT	12-DEC-2007	
APPROVED	R. SCHMITT	12-DEC-2007	
USED ON			
MATERIAL			
5. DRAWING UNITS: U.S. INCH			
FERMI NATIONAL ACCELERATOR LABORATORY UNITED STATES DEPARTMENT OF ENERGY			
FLARE UTILITIES GAS PIPING & INSTRUMENT DIAGRAM LIQUID ARGON PURITY DEMONSTRATION			
SCALE	DRAWING NUMBER	SHEET	REV
NONE	3942.510-ME-444897	2 OF 4	M
CREATED WITH: Ideas12NXSeries   GROUP: PPD/MECHANICAL DEPARTMENT			


















UNLESS OTHERWISE SPECIFIED			ORIGINATOR	R. SCHMITT	26-JUN-2007
			DRAWN	J. CATALANIELLO	07-DEC-2007
			CHECKED	R. SCHMITT	12-DEC-2007
			APPROVED	R. SCHMITT	12-DEC-2007
1. BREAK ALL SHARP EDGES 2. DO NOT SCALE DRAWING 3. DIMENSIONS BASED UPON ASME Y14.3M-1994 4. MAX. ALL WASH. SURFACES			USED ON		
5. DRAWING UNITS: U.S. INCH			MATERIAL		
					
FERMI NATIONAL ACCELERATOR LABORATORY UNITED STATES DEPARTMENT OF ENERGY					
FLARE UTILITIES GAS PIPING & INSTRUMENT DIAGRAM LIQUID ARGON PURITY DEMONSTRATION					
SCALE	DRAWING NUMBER	SHEET		REV	
NONE	3942.510-ME-444897	4 OF 4		M	
CREATED WITH : Ideas12NXSeries   GROUP: PPD/MECHANICAL DEPARTMENT					








TANK RTD AND HEATER LOCATION REFERENCE



- NOTES:
1. POWER SUPPLY SWITCH MUST BE IN PARALLEL POSITION.
  2. WIRE MUST BE 12 AWG OR EQUIVALENT.
  3. JUMPERS MUST BE 8 AWG OR EQUIVALENT.

NOTICE: IMAGE OBTAINED FROM FERMI LAB WEB SITE  
This information is provided for REFERENCE use only.  
Not for MANUFACTURE, or DESIGN INFORMATION.  
All information contained in this document represents  
work sponsored by an agency of the U.S. Government.  
Neither the U.S. Government nor any agency thereof,  
nor Universities Research Association, Inc., nor any of  
their employees or officers, makes any warranty, express  
or implied, or assumes any legal liability or  
responsibility for the accuracy, completeness, or  
usefulness of any information, apparatus, product or  
process disclosed, or represents that its use would not  
infringe privately owned rights.

UNLESS OTHERWISE SPECIFIED			ORIGINATOR	D. MARKLEY	10-MAR-2010
			DRAWN	J. CATALANIELLO	10-MAR-2010
+			CHECKED	T. TOPE	05-AUG-2010
1. BREAK ALL SHARP EDGES MAX. 1/8"			APPROVED	T. TOPE	05-AUG-2010
2. DO NOT SCALE DRAWING.			USED ON		
3. DIMENSIONS BASED UPON ASME Y14.5M-1994					
4. MAX. ALL WASH. SURFACES ✓			MATERIAL		
5. DRAWING UNITS: U.S. INCH					
					
FERMI NATIONAL ACCELERATOR LABORATORY UNITED STATES DEPARTMENT OF ENERGY					
FLARE-UTILITIES ELECTRONICS PPD-PC4 LIQUID ARGON PURITY-LAPD S7-PLC CABINET WIRING DIAGRAM					
SCALE	DRAWING NUMBER			SHEET	REV
NONE	3942.520-EE-466801			2 OF 1	D
CREATED WITH: Ideo12NXSeries			GROUP: PPD/MECHANICAL DEPARTMENT		



UNLESS OTHERWISE SPECIFIED	ORIGINATOR	D. MARKLEY	10-MAR-2010
	DRAWN	J. CATALANELLO	10-MAR-2010
$\frac{1}{8}$ $\frac{1}{4}$ $\frac{3}{8}$	CHECKED	T. TOPE	05-AUG-2010
1. BREAK ALL SHARP EDGES.	APPROVED	T. TOPE	05-AUG-2010
2. DO NOT SCALE DRAWING.	USED ON		
3. DIMENSIONS BASED UPON ASME Y14.3M-1994			
4. MAX. ALL MACH. SURFACES	MATERIAL		
5. DRAWING UNITS: U.S. INCH			



FERMI NATIONAL ACCELERATOR LABORATORY  
UNITED STATES DEPARTMENT OF ENERGY

FLARE-UTILITIES ELECTRONICS  
PPD-PC4 LIQUID ARGON PURITY-LAPD  
S7-PLC CABINET WIRING DIAGRAM

SCALE	DRAWING NUMBER	SHEET	REV
NONE	3942.520-EE-466801	3 OF 1	D
CREATED WITH : Ideas12NXSeries		GROUP: PPD/MECHANICAL DEPARTMENT	
		v11.8.12 page 19	

NOTICE: IMAGE OBTAINED FROM FERMILAB WEB SITE




This information is provided for REFERENCE use only. Not for MANUFACTURE or DESIGN INFORMATION.


The information contained in this document represents work sponsored by an agency of the U.S. Government. Neither the U.S. Government nor any agency thereof, nor Universities Research Association, Inc., nor any of their employees or officers, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, product, or process disclosed, or represents that its use would not infringe privately owned rights.



NOTES:





1. POWER SUPPLY SWITCH MUST BE IN PARALLEL POSITION.
2. WIRE MUST BE 12 AWG OR EQUIVALENT.
3. JUMPERS MUST BE 8 AWG OR EQUIVALENT.




UNLESS OTHERWISE SPECIFIED		ORIGINATOR	D. MARKLEY	10-MAR-2010
		DRAWN	J. CATALANELLO	10-MAR-2010
		CHECKED	T. TOPE	05-AUG-2010
		APPROVED	T. TOPE	05-AUG-2010
1. BREAK ALL SHARP EDGES		USED ON		
2. DO NOT SCALE DRAWING.				
3. DIMENSIONS BASED UPON ASME Y14.5M-1994				
4. MAX. ALL WASH. SURFACES				
5. DRAWING UNITS: U.S. INCH		MATERIAL		
 FERMI NATIONAL ACCELERATOR LABORATORY UNITED STATES DEPARTMENT OF ENERGY				
FLARE-UTILITIES ELECTRONICS PPD-PC4 LIQUID ARGON PURITY-LAPD S7-PLC CABINET WIRING DIAGRAM				
SCALE	DRAWING NUMBER	SHEET	REV	
NONE	3942.520-EE-466801	4 OF 1	D	
CREATED WITH : Ideas12NXSeries		GROUP: PPD/MECHANICAL DEPARTMENT		

NOTICE: IMAGE OBTAINED FROM FERMI LAB WEB SITE  
This information is provided for REFERENCE use only.  
Not for MANUFACTURE, or DESIGN INFORMATION.  
All information contained in this document represents  
work sponsored by an agency of the U.S. Government.  
Neither the U.S. Government nor any agency thereof,  
nor Universities Research Association, Inc., nor any of  
their employees or officers, makes any warranty, express  
or implied, or assumes any legal liability or  
responsibility for the accuracy, completeness, or  
usefulness of any information, apparatus, product or  
process disclosed, or represents that its use would not  
infringe privately owned rights.






UNLESS OTHERWISE SPECIFIED	ORIGINATOR	D. MARKLEY	10-MAR-2010
	DRAWN	J. CATALANELLO	10-MAR-2010
	CHECKED	T. TOPE	05-AUG-2010
1. BREAK ALL SHARP EDGES	APPROVED		05-AUG-2010
2. DO NOT SCALE DRAWING	USED ON		
3. DIMENSIONS BASED UPON ASME Y14.5M-1994			
4. MAX. ALLOW. SURFACES	MATERIAL		
5. DRAWING UNITS: U.S.-INCH			
 <b>FERMI NATIONAL ACCELERATOR LABORATORY</b> UNITED STATES DEPARTMENT OF ENERGY			
<b>FLARE-UTILITIES ELECTRONICS</b> <b>PPD-PC4 LIQUID ARGON PURITY-LAPD</b> <b>S7-PLC CABINET WIRING DIAGRAM</b>			
SCALE	DRAWING NUMBER	SHEET	REV
NONE	3942.520-EE-466801	\$ OF 1	D
CREATED WITH : IDeas12NXSeries    GROUP: PPD/MECHANICAL DEPARTMENT			

NOTICE: IMAGE OBTAINED FROM FERMILAB WEB SITE

This information is provided for REFERENCE use only. Not for MANUFACTURE, or DESIGN INFORMATION.

All information contained in this document represents work sponsored by an agency of the U.S. Government. Neither the U.S. Government nor any agency thereof, nor Universities Research Association, Inc., nor any of their employees or officers, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product or process disclosed, or represents that its use would not infringe privately owned rights.

REV	DESCRIPTION	1	DATE
		DRAWN	DATE
A	UPDATE WIRE SIZES.	J.CATALANELLO	12-APR-2011
		D.MARKLEY	29-AUG-2011




NOTE:  
ITEM 5 MUST BE PHYSICALLY RESET ANY TIME  
THE ASSOCIATED INTERLOCK THERMOCOUPLE IS  
DISCONNECTED.


7	COM'L	RFI FILTER CORROM #5VR1 NDMAK #52K3857	2
6	COM'L	HAMMOND ENCLOSURE 16"x16"x7" STOCK # 9175192	1
5	COM'L	OMEGA LIMIT CONTROLLER #CN3261-407	2
4	COM'L	MAGNETIC CONTACTOR OMEGA #MC1-2-30-240	2
3	COM'L	OMEGA PDM4 MODULE	2
2	COM'L	SOLID STATE RELAY DC INPUT 10 A., AC OUTPUT OMEGA #SSR330DCT10	2
1	COM'L	GAS HEATER OMEGA #HAPT-122	2
ITEM	PART NO.	DESCRIPTION OR SIZE	QTY.
PARTS LIST			
UNLESS OTHERWISE SPECIFIED		ORIGINATOR	T.TOPE
		DRAWN	J.CATALANELLO
±		CHECKED	T.TOPE
		APPROVED	T.TOPE
1. BREAK ALL SHARP EDGES MAX. 2. DO NOT SCALE DRAWING. 3. DIMENSIONS BASED UPON ASME Y14.5M-1994 4. MAX. ALL MACH. SURFACES		USED ON	10-AUG-2010
		MATERIAL	
		5. DRAWING UNITS: U.S. INCH	
FERMI NATIONAL ACCELERATOR LABORATORY UNITED STATES DEPARTMENT OF ENERGY			
FLARE-UTILITIES ELECTRICAL SYSTEMS-DIAGRAMS FILTER REGENERATION GAS HEATERS			
SCALE	DRAWING NUMBER	SHEET	REV
	3942.520-EE-486145	1 OF 1	A
CREATED WITH : Ideos12NXSeries		GROUP: PPD/MECHANICAL DEPARTMENT	

NOTICE: IMAGE OBTAINED FROM FERMI LAB WEB SITE  
This information is provided for REFERENCE use only.  
Not for MANUFACTURE, or DESIGN INFORMATION.  
All information contained in this document represents  
work sponsored by an agency of the U.S. Government.  
Neither the U.S. Government nor any agency thereof,  
nor its employees or officers, makes any warranty, express  
or implied, or assumes any legal liability or  
responsibility for the accuracy, completeness, or  
usefulness of any information, apparatus, product or  
process disclosed, or represents that its use would not  
infringe privately owned rights.

REV	DESCRIPTION	DRAWN APPROVED	DATE
A	UPDATE WIRE SIZE.	J.CATALANELLO D.MARKLEY	12-APR-2011 29-AUG-2011



THE 12 HEATER PAIRS SUM TO 600W  
PINS C & D JUMPER THE HEATERS IN  
SERIES AT THE BULK HEAD CONNECTOR.



ITEM	PART NO.	DESCRIPTION OR SIZE	QTY.
6	COML	AUTOMATION DIRECT RELAY	1
5	COML	HAMMOND ENCLOSURE 16" X 16" X 7"	1
4	COML	FLEXIBLE POLYIMIDE HEATER W/LOW NOMINAL RATING 100W AT 120VAC PART #K020100C3-0009B	24
3	COML	RFI FILTER CORCOM PART #5VR1	2
2	COML	SOLID STATE RELAY W/LED STATUS INDICATOR DC INPUT, 25.0mg AC OUTPUT OMEGA #SSR330DC25	2
1	COML	OMEGA PDM4 PULSE CONTROL MODULE	2

UNLESS OTHERWISE SPECIFIED	ORIGINATOR	T.T.OPE	26-JUL-2010
±	±	±	±
±	±	±	±
±	±	±	±

1. BREAK ALL SHARP EDGES MAX.	APPROVED	T.T.OPE	05-AUG-2010
2. DO NOT SCALE DRAWING.	USED ON		
3. DIMENSIONS BASED UPON ASME Y14.5M-1994			
4. MAX. ALL WASH. SURFACES			
5. DRAWING UNITS: U.S. INCH			

FERMI NATIONAL ACCELERATOR LABORATORY UNITED STATES DEPARTMENT OF ENERGY
---

FLARE-UTILITIES ELECTRONICS PPD-PC4 LIQUID ARGON PURITY-LAPD TANK HEATERS ELEC SCHEM
--

SCALE	DRAWING NUMBER	SHEET	REV
	3942.520-EE-486142	1 OF 1	A
CREATED WITH : IDeas12NXSeries	GROUP: PPD/MECHANICAL DEPARTMENT		

NOTICE: IMAGE OBTAINED FROM FERMI LAB WEB SITE  
This information is provided for REFERENCE use only.  
Not for MANUFACTURE, or DESIGN INFORMATION.  
All information contained in this document represents  
work sponsored by an agency of the U.S. Government.  
Neither the U.S. Government nor any agency thereof,  
nor Universities Research Association, Inc., nor any of  
their employees or officers, make any warranty, express  
or implied, or assume any legal liability or  
responsibility for the accuracy, completeness, or  
usefulness of any information, apparatus, product or  
process disclosed, or represents that its use would not  
infringe privately owned rights.



4

3

2

1

REV	DESCRIPTION	DRAWN	DATE
		APPROVED	DATE
A	MISC. UPDATES AND ADD WIRE AWG SIZES AND GROUNDING.	J.CATALANELLO	11-APR-2011
		D.MARKLEY	29-AUG-2011



AUTOMATION DIRECT 4 POLE 24VDC  
TYPICAL RELAY DIAGRAM  
PART # QM4X1-D24  
(DE-ENERGIZED POSITION)

NOTE:

THE MOTOR IS EQUIPPED WITH AN EMBEDDED KLIXON SWITCH. THIS NORMALLY CLOSED SWITCH WILL OPEN WHEN THE MOTOR TEMPERATURE EXCEEDS 300°F. MOTOR ROTATION SHOULD BE CLOCKWISE WHEN VIEWED FROM THE FAN END OF THE MOTOR. IF PUMP ROTATION IS INCORRECT, INTERCHANGE ANY TWO OF THE 3 WIRES BETWEEN THE VFD AND PUMP. DO NOT INTERCHANGE ANY OF THE WIRES BETWEEN THE VFD AND POWER SOURCE.

NOTICE: IMAGE OBTAINED FROM FERMILAB WEB SITE  
This information is provided for REFERENCE use only. Not for MANUFACTURE, or DESIGN INFORMATION.  
All information contained in this document represents work sponsored by an agency of the U.S. Government. Neither the U.S. Government nor any agency thereof, nor Universities Research Association, Inc., nor any of their employees or officers, makes any warranty, express or implied, or assumes any legal liability or responsibility for the accuracy, completeness, or usefulness of any information, apparatus, product or process disclosed, or represents that its use would not infringe privately owned rights.

3	COML	ROXBURGH KMF310 3PH 10A 500VAC EMI/RFI FILTER NEWARK PART# 01M8075	1
2	COML	BARBER-NICHOLS BNCP-32B-000, LONG SHAFT ARGON PUMP TOTALLY ENCLOSED FAN COOLED (TEFC)MOTOR 0.75HP 380VAC 3PH 95HZ 2 POLE INVERTER DUTY MOTOR	1
1	COML	TOSHIBA TRANSISTOR INVERTER, VFS11-4007PL-WN (R5), SOURCE 3PH 380/500V 50/60HZ OUTPUT 2.3A 1.8KVA	1
ITEM	PART NO.	DESCRIPTION OR SIZE	QTY.

PARTS LIST

UNLESS OTHERWISE SPECIFIED		ORIGINATOR	T.TOPE	16-DEC-2010
		DRAWN	J.CATALANELLO	16-DEC-2010
±		CHECKED	T.TOPE	28-JAN-2011
1. BREAK ALL SHARP EDGES MAX. 2. DO NOT SCALE DRAWING. 3. DIMENSIONS BASED UPON ASME Y14.5M-1994 4. MAX. ALL MACH. SURFACES		APPROVED	T.TOPE	28-JAN-2011
5. DRAWING UNITS: U.S. INCH		USED ON		
		MATERIAL		



FERMI NATIONAL ACCELERATOR LABORATORY  
UNITED STATES DEPARTMENT OF ENERGY

FLARE-UTILITIES ELECTRONICS  
LAPD LIQUID ARGON PUMP  
WIRING DIAGRAM

SCALE	DRAWING NUMBER	SHEET	REV
	3942.520-EC-486497	1 OF 1	A
CREATED WITH : Ideas12NXSeries		GROUP: PPD/MECHANICAL DEPARTMENT	





4

3



2

1

REV	DESCRIPTION	DRAWN	DATE
		APPROVED	DATE




LOGIC TRUTH TABLE				
DEVICE	DISRIPTION	ON STATE	OFF STATE	COMMENTS
R1	ULTIMAX 1 OOH ALARM	ALARM	NORMAL	TRIP POINT=19.5
R2	ULTIMAX 1 OOH ALARM	NORMAL	ALARM	TRIP POINT=19.5
R3	ULTIMAX 1 OOH ALARM	ALARM	NORMAL	TRIP POINT=19.5
R4	ULTIMAX 1 OOH ALARM	NORMAL	ALARM	TRIP POINT=19.5
PS	ADC UOIMAX	ALARM	RUN	
R7	ULTIMAX 1 TROUBLE	NORMAL	TROUBLE	
R8	ULTIMAX 2 TROUBLE	NORMAL	TROUBLE	
R9	ULTIMAX 3 TROUBLE	NORMAL	TROUBLE	
R10	ULTIMAX 4 TROUBLE	NORMAL	TROUBLE	
RA1, 12, 5, 0, 2, 4, 18, 10	OOH ALARM SUM	ALARM	NORMAL	
RA1, 12, 5, 0, 2, 4, 18, 11	OOH TROUBLE SUM	NORMAL	TROUBLE	



NOTE:  
POSITION FOR HORN  
CARD SWITCHES

UNLESS OTHERWISE SPECIFIED			ORIGINATOR	D.MARKLEY	21-AUG-2012
			DRAWN	J. CATALANELLO	27-AUG-2012
+	+	+	CHECKED	D.MARKLEY	08-NOV-2012
1. BREAK ALL SHARP EDGES MAY			APPROVED	D.MARKLEY	08-NOV-2012

2. DO NOT SCALE DRAWING.	USED ON
3. DIMENSIONS BASED UPON	
4. MAX. ALL MACH. SURFACES	MATERIAL
5. DRAWING UNITS:	



UNITED STATES DEPARTMENT OF ENERGY

FLARE UTILITIES ELECTRONICS  
LBNE 35 TON PROTOTYPE  
ODH SYSTEM WIRING DIAGRAM

SCALE	DRAWING NUMBER	SHEET	REV
	3942.520-EE-489928	1 OF 1	
CREATED WITH : Ideas12NXSeries		GROUP: PPD/MECHANICAL DEPARTMENT	

CREATED WITH : Ideas12NXSeries GROUP: PPD/MECHANICAL DEPARTMENT

NOTICE: IMAGE OBTAINED FROM PERMILAB  
Computer Aided Design Group.  
This image is an uncontrolled document and may not be  
the current, approved version.  
This information is provided for REFERENCE use only.  
NOT FOR MANUFACTURE OR DESIGN INFORMATION.  
This information contains controlled data. This document  
may be controlled information if it is prepared, owned, or  
work sponsored by an agency of the U.S. government.  
Neither the U.S. Government nor any agency thereof,  
nor Universities, Research Association, Inc. nor any of  
their employees or officers, makes any warranty, express  
or implied, or assumes any legal liability or assumes  
responsibility for the accuracy, completeness, or  
usefulness of any data, information, product, or  
process disclosed, or represents that its use would not  
infringe privately owned rights.