

Work on Liquid Argon at Fermilab

Stephen Pordes
Fermilab Institutional Review
June 6-9, 2011

Outline

- Introduction
- Many individual topics
- Conclusion

Introduction Liquid Argon – Why

Liquid Argon is a powerful Scintillator (40,000 photons/MeV) and allows free electrons to drift meters under practical strength electric fields.

It presents an attractive Target Medium for:

Neutrino interactions where liquid Argon TPCs can produce bubble-chamber quality event images;

Dark Matter searches which exploit features of light and free charge produced in Argon by the recoiling nucleus to achieve excellent background rejection.

Introduction - Some Context (1)

Technique pioneered by ICARUS collaboration over 30 years under C. Rubbia.

Work at Fermilab started by A. Para in ~ 2004

Evolved into significant program at Fermilab, including

- R & D facilities at PAB and the Liquid Argon Purity Demonstration
- ArgoNeuT exposure to NuMI beam
- MicroBooNE experiment (E-974) about to undergo CD-2 review,
- Liquid Argon proposal in the LBNE (Long Baseline Neutrino Expt)
- DarkSide 50 Dark Matter Search
- LArSoft General Software Project for LArTPC detectors

Introduction - Some Context (2)

Institutions collaborating in hardware R & D:

- Yale - Syracuse (ArgoNeuT construction and exposure)
- Michigan State University (TPC electronics)
- M.I.T and Indiana University (Light readout)
- BNL (TPC electronics and TPC design)
- Princeton (depleted Argon recovery and special cryogenics)
- UCLA (development of infrastructure for QUPID)

Introduction Neutrino & Dark Matter Synergies

Technical Issues for Multi-ton Argon **Neutrino detector**:


- Chemical purity to allow electron drift (10's ppt O₂ equivalent),
- Chemical purity to allow light production and propagation
- Cryostat and Cryogenics and associated safety issues
- TPC design
- TPC readout electronics
- HV feedthroughs (>100 kV) and distribution
- Light Detection
- Data Acquisition
- Detector Materials Qualification

Introduction Neutrino & Dark Matter Synergies


Technical Issues for **Neutrino or DM** Argon detector:

- Chemical purity to allow electron drift (10's ppt O₂), (**ν and DM**)
- Chemical purity to allow light production and propagation (**ν and DM**)
- Cryostat and Cryogenics and associated safety issues (**ν and DM**)
- TPC design (**ν and DM**)
- TPC readout electronics (ν)
- HV feedthroughs (>100 kV) and distribution (**ν and DM**)
- Light Detection (**ν and DM**)
- Data Acquisition (**ν and DM**)
- Detector Materials Qualification (**ν and DM**)
- Shielding from environment radiation (**DM**)
- Radio-purity of detector materials (**DM**)
- Radio purity of Argon (**DM**)

Facilities – Liquid Argon Setup at the PAB



Facilities – Schematic of Materials Test Stand




Liquid Argon Materials Test System Features

Operation Features of Materials Test System


- External Filters regenerated in place
- Can insert materials into known clean argon
- Can insert materials after purging only or after pumping on them
- Can position materials into liquid and into ullage giving range of temperatures
- Can insert known amounts of contaminant gases
- Nitrogen-based condenser can maintain liquid for long (weeks) studies
- Internal filter-pump can remove contamination introduced by materials – 2hr cycle
- Argon sample points at source, after single-pass filters, and in cryostat gas and liquid

Measurement Features of Materials Test System

- Measure electron drift lifetime (0.3 milliseconds to 10 milliseconds)
- Measure Oxygen (0.5 ppb sensitivity) with oxygen meter (Delta-F & Tiger Optics)
- Measure H₂O in gas (0.5 ppb sensitivity) with water meter (Tiger Optics)
- Cryogenic data, Lifetime Data, analytic instrumentation data in single data-base
- Runs 24/7 unattended - except for filter regeneration and argon refills



Lifetime
Monitor
Analysis




Lifetime
Monitor a la
ICARUS

The PrM software interface displays various parameters and results. At the top, it shows the 'PrM' logo and a green status indicator. Below this, it lists 'Interval (Min)' as 120, 'Sets' as 1, and 'Liquid Status' as a green circle. A status bar indicates 'Waiting for Next Interval'. The 'Smoothing' is set to 40 and 'RMS Cut' to 10. The 'Run Number' is 3146, and the 'Run FileName' is 'C:\PrM Data\Run_03146.txt'. The 'Log File Path' is 'E:\'. The 'Results' section shows a table of data for Run 3146, including Diode Peak, Diode Time, Diode Baseline, Cathode Peak, Cathode Time, Cathode Baseline, Anode Peak, Anode Time, Anode Baseline, Cath Factor, Anode Factor, Anode True, Cathode True, and LifeTime. The 'O-Scope' section has checkboxes for CH 1, CH 2, CH 3, and CH 4. The 'Analysis Wave Choice' section has checkboxes for 'Smooth' and 'Raw' for each channel. A 'Print Form' button is located at the bottom right.

Results	
1/23/2009 4:51:05 PM	Anode Peak = 3.746e-03
Run = 3146 Pass = 1	Anode Time = 8.228e-04
Diode Peak = -3.680e-02	Anode Baseline = 1.073e-04
Diode Time = 6.000e-06	Anode Rise = 2.654e-05
Diode Baseline = -8.640e-04	Cath Factor = 1.724e00
Cathode Peak = -2.659e-03	Anode Factor = 1.138e00
Cathode Time = 1.380e-04	Anode True = 4.350e-03
Cathode Baseline = 2.599e-04	Cathode True = 5.032e-03
	LifeTime = 5.647e-03

Materials Test Stand Automation


Cryogenics Control Panel



Materials Test Stand

Typical data

Some data samples



	Material	Date test started	Preparation	Tests	Water [ppb]	Lifetime [ms]	LogBook #
1	Cleaning Solution	6/29/09	evac. 24 h	vapor/liquid	4	5	946
2	Vespel	7/9/09	evac. overnite	liquid/vapor	5-7	2-5, 4-6	960
3	MasterBond glue	7/16/09	purged 18 h	vapor/liquid	1.6	1.3- 2.9	974
4	Bostik	didn't pass submerging in the liquid argon					992
5	LEDs	7/31/09	purged 38 h	vapor	3.5	5	993
6	Carbon filter material	8/12/09	evac. 24 h	liquid/vapor	2	4-9	1000
7	962 FeedTru Board V2	10/12/09	evac. 24 h	vapor/warm	85	1-5	1062
9	Teflon cable	1/9/10	purged 28 h	warm/liquid/vapor	8-20	2-5	1175
10	3M "Hans" connectors	1/29/10	purged 46 h	warm/liquid/vapor	5-12	3	1198
11	962 capacitors	3/2/10	evac. 24 h	warm/liquid/vapor	6-14	3-6	1228
12	962 polyolefin cable	4/12/10	evac. 16 days	warm	25-60	2	1237
13	Rigaku feedthrough	4/20/10	purged 7.5 h	warm	15	3	1250
14	Rogers board (Teppei)	4/23/10	purged 26 h	warm/liquid/vapor	40	2, 6-10	1254
15	Arlon Board (Teppei)	5/14/10	evac. 0.5 h, pur.2 days	warm/vapor	300, 80	1.3, 3.5	1263
16	Polyethylene tubing	5/24/10	evac. 6 h, pur. 66 h	warm	300-500	1	1278
17	Teflon tubing	5/27/10	evac. 1 h, pur.17 h	warm	9-13	4-5	1283
18	Jonghee board	5/28/10	evac. 6 h, pur. 1.5 h	warm/vapor	100,28	1.2, 5-8	1285
19	Jonghee connectors	6/4/10	evac. 3.5 h, pur. 16 h	warm/vapor	50	2-3	1290
20	PVC cable	6/14/10	evac. 29 h, pur.1 h	warm	120	1-2	1296
21	Teppei TPB samples	8/3/10	purged 26 h	warm	600-1600	0.7	1342

Materials Test Stand Summary

Filter Materials:

Industrial filter materials are capable of removing all electronegative materials (water, oxygen) and producing liquid with >10 milliseconds lifetime.

Data on filter capacity at our requirements are sparse;

Filters can be regenerated many times; we know how - using non-flammable Ar-H mix

Materials:

Materials immersed in the liquid have no effect on lifetime;

Materials immersed in warm gas volume above the argon have:

- no effect on lifetime if the argon is venting at a certain rate;

- significant effect if the warm gas mixes with the liquid argon directly;

- metal surfaces outgas water vapor at significant rate and ... see above

Contaminants:

Absent leaks, water is the main concern; it comes from detector materials and the cryostat walls in the warm gas.

`A system to test the effects of materials on the electron drift lifetime in liquid argon and observations on the effect of water' R. Andrews *et al.*, Nucl.Instrum.Meth.A608:251-258,2009.

LAr TPC Electronics Test Stand




1st LAr TPC with U.S.
electronics readout



50 cm vertical drift TPC
HV 20 - 30 kV
3 planes of wires at 120°





LAr TPC Raw Signals




few channels show a hit




all channels show a hit




all channels show a hit



Served as the test bed for development of ArgoNeuT electronics, and motivated the development of software hit reconstruction techniques based on FFT.



Example of use of TPC data – for electronics development



Ionization signals are small ($\sim 15,000$ e) and slow – important to restrict bandwidth of system. Note the signal region is broader with filters B & D which have acceptance at lower frequency. These sort of data were used to optimize front-end filter bandwidth for resolution and two-track separation.

Electronics Test System: in-liquid electronics


For enormous (multi-kiloton) LAr TPCs, there are significant advantages in being able to put the **electronics in the liquid** argon and **to multiplex the signals** before transmitting them out of the cryostat.

Advantages:

- Lower capacitance seen by the first amplifier close to the wire leads to better signal to noise
- Ability to put amplifiers anywhere required avoids either having to bring all signals to top of detector, or to have feed-throughs in liquid.
- Multiplexing signals reduces number of feed-throughs and thus reduces cost and chance of leaks.
- Multiplexing signals reduces cable plant inside detector and thus reduces sources of contamination and out-gassing.

1st in-liquid CMOS electronics on a LArTPC





Built at Michigan State University




CMOS based design.

- Available technology.
- Operates well at 90K.
- Can be converted into ASIC.
- Capacitors and Inductors require careful selection.
- Connectors and cabling need careful testing.
- Ground connections need robust mechanics.

In-liquid electronics Raw Data




All 144 channels work




S/N looks promising

Analysis in progress



PPD EE dept. looking at long term issues to do with operation at low T

ArgoNeuT-T962: LArTPC exposed to NuMI Beam




FNAL, Italy, MSU, Syracuse,
Yale

1m x 50 cm x 50 cm
2 views $\pm 30^\circ$ to vertical
480 channels total

Ran in NuMI beam
neutrino (1 month)
anti-neutrino (4 months)

ArgoNeuT event with 4 photon conversions



Invaluable data set on ν interactions in Argon
Analysis in progress – results in Summer

Achieving good lifetime in an unevacuated vessel

Liquid Argon Purity Demonstration


Demonstrate good life-time in an industrial vessel without evacuation. All previous detectors have been evacuated before filling

Atmosphere will be removed by 'argon' piston, then argon gas will be circulated through filters to achieve ~ 1 ppm Oxygen.

Heaters in the insulation can warm the walls to 60 C.

Filtration system sized for 30 tons of Argon at 1 ppm Oxygen. Pump will circulate entire volume in <24hrs.


Expect to start commissioning at the end of May.



Electron Drift-Lifetime Measurement and ...

Measure evolution of gas-purge using exhaust tubes at different heights (sniffer);
Measure liquid temperatures throughout tank and compare with models to understand convective flow

Instrumentation for LAPD:



Analytic Equipment

Oxygen meters (0.4 ppb sensitivity)

H20 meters (0.5 ppb sensitivity)

N2 meter (20 ppb sensitivity)

can sample multiple points

In the Tank

2 sets of 2 PrM (20 cm / 60 cm)

2 sets of 3 translating RTDs


Sniffer set to measure purge evolution

Inline

Purity Monitor


Some steps on the path to the LBNE 25 ktonne cryostat
based on Membrane panel construction as used in LNG carriers
Well-suited to construction in a cavern.

LAr 35t




Demonstration of
the membrane
cryostat technology

LAr1




Prototype of the
LAr20 detector
validating TPC
design and the
assembly
procedures.

LAr20



One module of the
LBNE detector

LNG tanker membrane cryostat




The LNGC "Tembek", one of the thirty-one 216,000 m³ LNG carriers ordered by Nakilat and delivered in 2008




First steps with the Membrane Technology

Assembly of first membrane panel showing: delivery crate, (from Korea to Fermilab), insulation backing, weld between two overlapping panes, and 3 panel section ready for leak testing.




Need some R & D to develop alternative leak-checking procedures to avoid use of contaminating chemicals

Plans for siting LAr35t and LAr1



Showing the LAr35t cryostat using the same cryogenics and purification system as developed for the Liquid Argon Purity Demonstration



The LAr1 (ktonne) is intended to be built in the DZero pit where there is already significant liquid argon infrastructure.

Light Readout R & D (M.I.T & Indiana)


Light signal might be a useful trigger. Argon light is 128 nm and wave-length-shifters (WLS) are used to convert the 128 nm to visible.

Typical arrangement is for PMTs with WLS around the periphery.

This is both costly (paying for PMT area) and inefficient for large volume detectors. Can one wave-length shift and collect light throughout volume and route it to photodetectors?

A concept: clear polystyrene light guide clad with thin layer of WLS in a polystyrene matrix. Issue is attenuation length along the light-guide because of the cladding layer.

A sample of polystyrene bar co-extruded (by the NICADD extruder) with an outside layer of polystyrene containing 1.5% bis-MSB. Note the blue is only evident at the surface, not throughout the volume.



LAr for Dark Matter: Depleted Argon Distillation Column

Atmospheric Argon contains 1 part in 10^{15} of ^{39}Ar , half-life ~ 270 yrs, end-point 565 keV.

This gives a background rate of 1 Bq/kg which limits the size of LAr Dark Matter 2-phase TPCs to ~ 1 ton because of dead-time.

The ^{39}Ar comes from interactions of cosmic rays on ^{40}Ar in the atmosphere. Underground Argon is not subject to these interactions.

Commercial CO_2 wells have been found * which contains 400 ppm Argon with $< 1/25$ (measurement limit) the atmospheric concentration.

This Argon represents an unique resource for the Dark Matter program.

After removal of the CO_2 a mixture of 3% Ar, 27% He and 74% N_2 is obtained. Fermilab Has agreed to host the distillation column designed to separate the Argon.

The basic column was designed at Princeton. It was assembled, safety reviewed and has had its first run at FNAL.

* 2008 J. Phys.: Conf. Ser. 120 042015



Distillation Column Design and Realization

Designed to produce 99.999% pure Ar




Looking up the column




Column packing material

66 stages



First Distillation – Batch Mode works



Can distill efficiently but only in batch mode

Upgrades planned to improve cooling at input to achieve continuous distillation

Cryo-Booster (to put Argon into high pressure cylinders) is to be brought online

One Slide on Software

It is recognized that detector simulation and event reconstruction are important for the success of the Lar technology, and present a significant challenge given the wealth of data the detector provides.

LArSoft is a framework for Detector Simulation and Reconstruction in Liquid Argon TPCs.

It is supported by the Fermilab Computing Division in its ART framework.


It provides many types of event (Cosmic Ray, Neutrino Interaction, Single Particle) and propagates the resultant charge (and light) through the Argon.

The user defines the detector geometry and signal processing.

LArSoft has contributors from:

Bern (CH), Columbia University, Fermilab, LNGS (It), Kansas State University, M.I.T., Michigan State University, Syracuse and Yale.

LArSoft Simulation of a π^0 in ArgoNeut - cf slide 22



Conclusions

Vigorous and broad range of activities in Liquid Argon
Stimulating technical challenges and a collaborative environment
Comprehensive program of tests and prototypes towards LBNE
and/or other deployment of multi-kiloton detectors
Synergies with Dark Matter searches recognized and exploited
Recognition of the importance of simulation and reconstruction
software and a serious commitment to their development.

Backups

Introduction Neutrino & Dark Matter Synergies

Technical Issues for **Neutrino or DM** Argon detector:

- Chemical purity to allow electron drift (10's ppt O₂), (**ν and DM**)
- Chemical purity to allow light production and propagation (**ν and DM**)
- Cryostat and Cryogenics and associated safety issues (**ν and DM**)
- TPC design (**ν and DM**)
- TPC readout electronics (ν)
- HV feedthroughs (>100 kV) and distribution (**ν and DM**)
- Light Detection (**ν and DM**)
- Data Acquisition (**ν and DM**)
- Detector Materials Qualification (**ν and DM**)
- Shielding from environment radiation (DM)
- Radio-purity of detector materials (DM)
- Radio purity of Argon (DM)

Issues being addressed

