

LArIAT Group Meeting

Brandon Soubasis, Will Flanagan, Dung Phan

The University of Texas at Austin





20 May 2016

Aerogel

- ❖ Instructions used to produce analysis using LArSoft
<https://cdcv.s.fnal.gov/redmine/projects/lardbt/wiki/AGCodes>
- ❖ Our naming convention for the four aerogel PMTs is:
US E/W are the two PMTs for the KEK counter
(Hamamatsu H1161)
DS 1 is (the 3" square Photonis XP5382 PMT)
DS 2 is (the 2" circular EMI 9954B PMT.)





Aerogel Pulse Area

❖ Pulse Area for each PMT with & without aerogel hit exist cuts applied




Aerogel Pulse Area

- ❖ Pulse Area for each PMT with aerogel hit exist cuts applied below 1000ADCns
- ❖ Unable to see a single P.E
- ❖ Is this an affect from our pulse area algorithm?



TOF



- ❖ TOF allows for π/μ & proton separation
- ❖ TOF + WC's you can do particle ID (π/μ , p, K) before the particle enters your LArTPC.





Pulse Area vs. TOF

❖ Using runs 6258-6265(Positive Polarity)

KEK:





UT:





Pulse Area vs. TOF

- ❖ Using runs 6100-6329(Negative Polarity)
- ❖ We can focus on just on muons and pions separation analysis.

KEK:




UT:



TOF



- ❖ Positive polarity data has protons, so by studying negative polarity data, we are able to focus strictly on the analysis of π - μ separation since anti-protons rarely show up in our negative polarity data. A preliminary particle identification hypothesis is possible utilizing the TOF and wire chamber track momentum profile for positive polarity data. π/μ events should lie between $0 \text{ ns} < \text{TOF} < 225 \text{ ns}$ and $100 \text{ MeV/c} < P < 1500 \text{ MeV/c}$.





Pulse Area vs. TOF

- ❖ We can now focus studies on π - μ separation for positive polarity. Pulse area vs TOF from each aerogel Cherenkov detectors PMT is shown following the TOF selection cuts made for eliminating protons.

KEK:





UT:





Aerogel Analysis

- ❖ Aiming to separate muons and pions in a momentum range where muons emit Cherenkov radiation while pions do not.
- ❖ Different indices of refraction are sensitive to different momentum ranges.
- ❖ The combination of the two aerogel Cherenkov counters, pions and muon can be identified for $p < 400 \text{ MeV/c}$

Aerogel Counter	$n=1.11$	$n=1.057$
200-300 MeV/c	π μ	π μ
300-400 MeV/c	π μ	π μ



MC Beam Composition Studies



- ❖ How can we use beam simulation help understand the aerogel counters?
- ❖ How can we use aerogel counters help understand the beam simulation?

MC Beam Composition Studies (Ideal Case)

- ❖ We can set constraints to the WC by requiring hits in the AG counter
- ❖ We can assume efficiencies for muons and pions to be:

Aerogel Detector index $n=1.05$

0% for $p_\mu < 310\text{MeV}$, 100% for $310\text{MeV} < p_\mu$

0% for $p_\pi < 440\text{MeV}$, 100% for $440\text{MeV} < p_\pi$


Aerogel Detector index $n=1.103$

0% for $p_\mu < 220\text{MeV}$, 100% for $220\text{MeV} < p_\mu$


0% for $p_\pi < 310\text{MeV}$, 100% for $310\text{MeV} < p_\pi$

MC Beam Composition Studies (Ideal Case)


Requiring a hit in the n=1.057 counter



Requiring a hit in the n=1.103 counter




Requiring a hit in the n=1.103 counter but not the n= 1.057





WC Information

- ❖ Getting the X and Y position from the WC of a track at the TPC front face.
- ❖ Working on projection of WC tracks to aerogel counters.



- ❖ Requiring that an hit exist from each aerogel counters(1.057 and 1.1103)




WC Infomation


- ❖ Calculate the efficiency for requiring hits in each AG counter.

$$\varepsilon_{track} = \frac{WC \text{ requiring AG hit}}{Total \text{ WC hits}}$$

Efficiency of AG n=1.057




Efficiency of AG n=1.103




WC Momentum & Aerogel

- ❖ Total WC momentum with Aerogel hit exist requirements
- ❖ This is positive polarity data with no cuts to get rid of protons.
- ❖ This is 100A data where all muons and pions should be above Cherenkov threshold.




$$\epsilon_{momentum} = \frac{WC_{momentum} \text{ require AG hit}}{Total WC_{momentum}}$$



- ❖ The efficiency of the wire chamber momentum when requiring hits from each aerogel Cherenkov detector. n=1057 becomes more efficient at the lower momentum.
- ❖ We can see clear a region where we identify particles at less then 400MeV/c

Beamline Simulation

- ❖ Add aerogel counter in the G4Beamline Simulation(Currently testing)



APPROXIMATION: the octagonal Cherenkov2 is approximated as a circle

APPROXIMATION: an additional window is used in place of the mirror

- material aerogel density=0.2 Si,0.292 O,0.666 H,0.042
- tubs Cherenkov2Window outerRadius=400 length=1.0 material=Al color=0,0,1
- virtualdetector Cherenkov2 radius=425 length=100 material=aerogel color=0,0,1 tubs Cherenkov2Light outerRadius=640 length=367 material=Air color=1,1,1 material calorimeter density=3.7 Pb,0.85 scintillator,0.15
- virtualdetector Calorimeter width=1200 height=1200 length=160 material=calorimeter color=0,1,1

<http://muonsinc.com/muons3/g4beamline/G4beamlineUsersGuide.pdf>

Conclusion

- ❖ Scanning over remaining negative and positive polarity data to increase statistics and see if can have a better look at the Bethe-Bloch dependence.
- ❖ Calculate the efficiencies for detecting pions vs protons for pulse area versus TOF.
- ❖ We can now get the position of hits for each wire chamber?
- ❖ Next: I will use the wire chamber information in the anatree is able to tell us the X and Y position of a particle in WC3 and WC4 to estimate the position of particles passing through the aerogel counters. Then calculate the efficiencies for each aerogel counter for hints of separation.