PAB Materials Test System	
Date of Receipt	3/3/2010, logbook entry #1198
Sample Name/Description	3M connectors(10 Boardmount Header 81020-550203
	and 9 Wiremount Socket 82020-6006)
Sample	
Composition:	Boardmount - High Temp. Plastic(LCP), Wiremount - Glass Filled Polyester(PBT)
Picture Location:	
Weight:	48.5 g (10 boardmount -26.7 g , 9 wiremount -21.8 g)
Dimensions/Area:	1 boardmount apx. 27.2 x 10.5 x 7.8 mm, wiremount 19 x 9.6 x 6 mm
Source:	Walter Jaskierny, Hans Jostlein
Preparation:	cleaned with alkohol
Submerging in LAr or LH2	no
Zero Test	1/29/10 - 2/1/10
Lifetime:	from 10 ms to 3.1 ms
Time in the airlock(hrs)	46 h
Purge:	2/1/10 10:10 am, 2/3/10 8:40 am
Vacuum:	
Room Temperature	
Start Time/Date, End Time/Date :	2/3/10 8:42 am, 2/8/10 8:55 am
PrM run # :	7305-7371
Condenser state:	on
Filter state:	off
O2 reading:	increased by 0.5 ppb
H2O reading:	12.3 ppb HALO , 2.8 ppb LaserTrace
Lifetime:	10 ms to 2.7 ms
Liquid Test	
Start Time/Date, End Time/Date :	2/9/10 9:10 am, 2/10/10 3:45 pm
PrM run # :	7384-7427
Condenser state:	on
Filter state:	off
O2 reading:	increased by 0.3-0.1 ppb
H20 reading:	increased to 11 ppb, stabilized at 5-6 ppb
Temperature:	95.4 K
Lifetime:	from 10 ms to 4.9 ms, stabilized at 6-7 ms
Liquid level :	22" to 21"
Vapor Test	
Start Time/Date, End Time/Date:	2/11/10 9:10 am, 2/16/10 9:10 am
PrM run # :	7437-7546
Condenser state:	on
Filter state/settings:	off
O2 reading:	increased by 0.85 ppb initially, then started to go down.
H20 reading:	stabilized at 3.5-5 ppb
Temperature:	220-225 K
Lifetime:	stabilized at 6-7 ms
Zero Test	2/19/10 - 2/22/10
Lifetime:	from 9.5 ms to 0.6 ms(apparatus problem, unexpected water increase)
Results/comments	Test shows that 3M connectors don't have a big effect on the purity
	of the liquid Ar.